

PLATE NO=1	PART NO	DESCRIPTION
	5402380456	CYLINDER (GRADE A) WHITE COLOUR MARK
	5402380457	CYLINDFR (GRADE B) RED COLOUR MARK
	5402380458	CYLINDER (GRADE C) GREEN COLOUR MARK
	50006166	JOINT
	53006166	JOINT
	40002560	CRANKCASE WITH BUSH AND PIN
	40002578	CRANKCASE WITH BUSH AND PIN (BSII)
	40002550	CRANKCASE WITH BUSH AND PIN
	40002263	BUSH STD.
	40002264	BUSH 0.25 MM U/S
	40002265	BUSH 0.5 MM U/S
	40002266	BUSH 0.75 MM U/S
	40002267	BUSH 1 MM U/S
	276846055	DOWEL PIN
	5406850106	STUD CYLINDER HEAD
	5406850108	STUD CYLINDER HEAD
	271678054	STUD F.W.E.SIDE
	50000506	STUD ENGINE FEET
	50008099	OIL PAN CHAMBER
	50006169	JOINT
	250755507	SPRING WASHER
	406177005	BOLT
	5001745002	SUCTION BULB
	97626048	PLAIN WASHER
	40016141	JOINT- SUCTION BULB
	1177001	BOLT
	200467003	JOINT
	50008924	DIPSTICK
	50000421	MAGNETIC DRAIN PLUG
	53011748	COVER (PTO)
	90303028	NEEDLE BEARING
	50006328	OIL SEAL
	50006101	JOINT 0.4 MM
	500460120	JOINT 0.2 MM
	500460102	JOINT 0.3 MM
	40016137	JOINT 0.2 MM
	40016136	JOINT 0.3 MM
	40016142	JOINT 0.4 MM
	47177007	HEX HEAD SCREW
	53000542	STUD
	40011772	CRANKSHAFT SUPPORT ASSY. GL400
	40011753	CRANKSHAFT SUPPORT ASSY. WITH STD. BUSH AND OIL SEAL
	40002268	BUSH F.W.E. SIDE
	40002269	BUSH 0.25 MM U/S
	40002270	BUSH 0.50 MM U/S
	40002271	BUSH 0.75 MM U/S
	40002272	BUSH 1 MM U/S
	500121092	OIL SEAL
	500470103	JOINT 0.2 MM
	500470094	JOINT 0.3 MM
	SK-8832	RETAINER PLATE

	9324018	NUT
	50000613	MACHINED WASHER
	250467014	JOINT-DRAIN PLUG
	40641	GUIDING BOLT (BSII)
	40642	WASHER(BSII)
PLATE =2	40008363	CYLINDER HEAD ASSY. CONSISTING OF SR.NO.1,3 TO6
	40008384	CYLINDER HEAD ASSY (BSII)
	43506183	JOINT CYLINDER HEAD 0.9 MM
	43506182	JOINT CYLINDER HEAD 0.8 MM
	43506181	JOINT CYLINDER HEAD 0.7 MM
	43506180	JOINT CYLINDER HEAD 0.6 MM
	43506184	JOINT CYLINDER HEAD 1 MM
	40016143	JOINT CYLINDER HEAD 0.5 MM
	40016144	JOINT CYLINDER HEAD 0.55 MM
	5508000117	INLET VALVE SEAT
	5508000118	EXHAUST VALVE SEAT
	40002254	INLET VALVE GUIDE
	40002256	INLET VALVE GUIDE 0.5 MM O/S
	40002255	EXHAUST VALVEGUIDE
	40002257	EXHAUST VALVE GUIDE 0.5 MM O/S
	500450092	JOINT-INTAKE FLANGE- AIR INTAKE
	40016139	JOINT-INTAKE FLANGE- AIR INTAKE
	5005755045	VALVE SPRING
	5003430070	DISC
	500213572	CAP, INLET VALVE
	500641036	COLLET ASSY.
	5509652099	INLET VALVE
	5509685104	EXHAUST VALVE
	9324076	NUT
	D-40165	DOME NUT
	9762665	PLAIN WASHER
	500676035	STUD
	50000506	STUD, EXHAUST
	268120034	O" RING
	D-40580	DECOMPRESSION SHAFT ASSY
	505568046	RETURN SPRING
	50000901	SPRING DOWEL
	500193049	LOCK SCREW
	260467001	JOINT
	9467001	JOINT
	D-31126	AIR CLEANER ASSY.
	50008650	FLANGE AIR CLEANER
	41752	ELEMENT
	D-41092	ELEMENT
	40000549	STUD, AIR INTAKE
	40000550	STUD,AIR INTAKE
	D-41155	"O" RING
	31116	SCREW
	16408	SPRING WASHER
	587886	RUBBER BELLOW
	567879	GASKET
	40002258	SET OF VALVE GUIDE

40002259	SET OF VALVE GUIDE 0.5 MM O/S
400022104	SET OF VALVES (BSII)
40002261	SET OF VALVE
50006610	ROCKER COVER BOX ASSY.CONSISTING OF SR.NO.38 TO 49
41789	ROCKER COVER BOX ASSY LM TYPE
5402125627	ROCKER COVER BOX ASSY WITH COVER O RING & OIL FILLTEP
53006612	ROCKER COVER BOX ASSY.CONSISTING OF SR.NO.38 TO 49
53011752	ROCKER BOX COVER WITH TUBE
50016130	JOINT-COVER PLATE
50010696	COVER PLATE
50000161	COUNTER SUNK SCREW
D-41158	PLUG
D-40517	RUBBER RING
2609695004	BREATHER VALVE
50000664	PLATE BREATHER PLUG
225324004	NUT
45175504	SCREW BREATHER PLUG
26756503	SPRING WASHER
705085012	PLATE-BREATHER
40016138	JOINT
904850603	LIFTING HOOK
50000157	BOLT (HEX HEAD)
50000114	BOLT (ALLEN)
250755507	SPRING WASHER
604552	CLAMP
604553	CLAMP
567694	CLAMP
567695	CLAMP
6548960144	EXTENSION PIPE
50017128	PIPE
SK-2924	CLAMP
ED41745	ELEMENT (KUBOTA TYPE)
ED22108	AIR CLEANER ASSY.(KUBOTA TYPE)
569381	FLANGE ASSY PLASTIC (N.I)
569451	GASKET FOR FLANGE
569460	AIR CLEANER RUBBER BELLOW(KUBOTA TYPE)
ED42400	AIR FILLTER
ED42502	ELEMENT (ENGINIETECH)
632428	ELEMENT (ENGINIETECH)
42500	DUST VALVE (ENGINETECH)
42501	O RING (ENGINETECH)
42503	KNOB (ENGINETECH)
1965755128	SPRING LM TYPE
632061	ELECTRIC AIRWARN INDICATOR
632229	ELEC AIR WARM FILLTER MOUNTING BRACKET
632425	COVER ENGINETECH AIR FILLTER
604750	BRACKET FOR ENGINETECH FILLTER
611619	HOSE ENGINE ENGINETECH
611620	HOSE FOR FLANGE ENGINTECH
604552	CLAMP FOR HOSE FLANGE
604756	CLAMP FOR HOSE ENGINE
611621	PLASTIC FLANGE ENGINTECH

	604553	CLAMP FOR HOSE ENGINE
	632413	RUBBER PACKING
	632414	STRAP ASSY COMPLATE ENGINETECH
	604756	CLAMP FOR HOSE ENGINE
PLATE =3	50006060	CRANKSHAFT SUPPORT ASSY. WITH STD. BUSH AND OIL SEAL
	500228048	KEY -F.W.E.
	500125708	THRUST WASHER
	47177007	BOLT
	40010597	PISTON ASSY STD.(GRADEA)WHITE COLOUR MARK CONSISTIN
	40020509	PISTON ASSY A MOD BS-II
	400105201	PISTON GRADE A(BSII)
	400105202	PISTON ASSY A BSII
	4001050203	PISTON GRADE A(BSII)
	40020512	PISTON ASSY C MOD BS-II
	40020510	PISTON ASSY B MOD BS-II
	40010598	PISTON ASSY.STD.(GRADE B)RED COLOUR MARK CONSISTION
	40010599	PISTON ASSY STD.(GRADE C) GREEN COLOUR MARK 6.7.8
	400105100	PISTON ASSY.0.5 MM O/S CONSISTION OF SR.NO.6,7,8
	400105101	PISTON ASSY. 1.0 MM O/S CONSISTING OF SR.NO.6,7,8
	40001428	PISTON RING SET STD.
	40001429	PISTON RING SET 0.5 MM O/S
	40001430	PISTON RING SET 1.0 MM O/S
	5408480091	PISTON PIN
	3124017	CIRCLIP
	50009023	CONNECTING ROD ASSY. CONSISTING OF SR.NO.9;10,11
	50009005	SMALLEND BUSH
	97626048	WASHER HARDENED
	50000644	LOCK PLATE
	50000160	BOLT
	D-30640	LARGE END BEARING STD.
	D-40718	LARGE END BEARING 0.25 MM U/S
	D-41933	BARRAL PISTON KIT
	40020513	BP KIT BS-II
	42396	CON ROD BOLT KIT
	D-42982	BP KIT BS-II
	D-40719	LARGE END BEARING 0.50 MM U/S
PLATE=4	500101150	CAM SHAFT
	400060112	CAM SHAFT BSII
	500141016	PUSH ROD
	50007334	SET OF PUSHES
	5009520029	PUSH ROD TUBE
	500474018	SLEEVE-PUSH ROD TUBE
	500474025	SLEEVE -PUSH ROD
	D30956	PIN LH THREAD
	500614080	PIN
	500755006	DISTANCE PIECE
	47124004	CIRCLIP
	5005271054	CAM FOLLOWER LEVER
	52005171	SET OF CAM FOLLOWER LEVERS
	540605438	ROCKER FULCRUM
	53005167	INLET ROCKER LEVER ASSY. CONSISTING 12,13,14

	53005136	ROCKER LEVER INLET
	500985048	ADJUSTING SCREW
	105324008	NUT
	53005168	EXHAUST ROCKER LEVER ASSY.CONSISTING OF SR.13,14,16,17
	53005137	ROCKER LEVER EXHAUST
	505985052	DECOMPRESSOR OPERATING SCREW
	53005170	SET OF ROCKER LEVER
	50006190	SET OF SLEEVE PUSH ROD TUBE
	53005170	SET OF CAM FOLLOWER
PLATE =5	500493620	GOVERNOR GEAR
	500208572	GOVERNOR BELL (STEEL)
	500116011	CIRCLIP
	3824509	BALL
	202756511	SPRING WASHER
	500324066	NUT
	276843023	TAPER PIN
	5406140483	PIN-FDC LEVER
	7102800049	SPLIT PIN
	9843023	DOWEL PIN
	5005801462	SPRING- EXCESS FUEL
	5006371045	ANCHOR PLATE
1	400051135	FUEL PUMP R C LEVER ASSY (BSII)
	5405200997	R.C. LEVER ASSY.
	9756504	SPRING WASHER
	9176005	SCREW
	264973008	HEX.SOCKET HEAD SCREW
	40006741	LUB OIL PUMP ASSY.
	50000437	HEX SOCKET HEAD SCREW
	1756504	SPRING WASHER
1	9176007	SCREW
1	9176005	BOLT M6X19 16 FOR FDC LEVER (BSII)
1	264973008	HEX SOCKET HEAD SCREW
1	52006709	LUB OIL PUMP ASSY.
1	1756504	SPRING WASHER
1	50000437	HEX SOCKET HEAD SCREW
	250755504	SPRING WASHER
	50010103	GOVERNOR LEVER ASSY.
	500520134	GOVERNOR LEVER (INNER)
	51981002	SCREW
	500220013	KEY
	40001816	FLANGE ASSY. L O FILTER
	D-21235	FLANGE
	50008711	FILLTER SPIN-ON TYPE
	D-41208	STUD
	50006495029	PISTON
	50001213143	O"RING- LUB OIL FILTER
	50005625006	SPRING
	9041202013	"O" RING
	260973026	HEX SOCKET HEAD SCREW
	1756507	SPRING WASHER
	1177001	BOLT

	200467003	JOINT
	260120016	O RING
	9120016	"O" RING
	560968013	RELIEF VALVE BODY
	500968013	RELIEF VALVE BODY
	500575549	SPRING
	200467021	JOINT
	D-40516	PIUG-RELIEF VALVE
	1762507	PLAIN WASHER FOR M6 FOR FDC LEVER (BSII) (NI)
	D- 41447	OIL PRESSURE SWITCH-PARALLEL THREAD
	105324008	NUT M6*1 FOR FDC LEVER (BSII) (N.I.)
	SK-4656	OIL PRESSURE SWITCH
PLATE =6	50010167	COVER REMOTE THROTTLE STOP CONTROL ASSY.SR NO.2,6,12
	50007596	COVER
	500520214	EXTERNAL STOP LEVER
	9842002	TAPER PIN
	105324008	NUT
	1756504	SPRING WASHER
	50000452	TERMINAL
	50010606	SUPPORT
	90600031	CABLE ANCHOR
	D-41228	SCREW
	105324008	NUT
	5005680044	SPRING STOP LEVER RETURN
	9176003	BOLT
	500520260	STOP LEVER INTERNAL
	407176003	SCREW COVER FIXING
	7500428	MAX SPEED SETTING BOLT
	105324008	NUT
	9176028	MIN SPEED SETTING BOLT
	9324008	NUT
	5208576045	EXCESS FUEL BOLT
	270973010	SCREW
	400101102	EXCESS FUEL DEVICE ASSY. (BSII)
	500324058	NUT FOR EXCESS FUEL BOLT
	9973010	SCREW GOVERNOR SUPPORT FIXING
	5208785129	GOVERNOR SUPPORT ASSY. SR NO 4 6,11.22,30
	40009644	SUPPORT GOVERNOR LEVER
	5005202010	LEVER- MAX FUEL
	5005200293	THROTTLE LEVER
	500568043	SPRING
	91200087	"O" RING
	5205200778	LOWER LEVER WITH PIN
	5005200777	UPPER LEVER WITH PIN
	40009645	GOVERNOR SPRING ASSY.
	5201160056	CIRCLIP
PLATE =7	50006806	FEED PUMP
	50006808	FEED PUMP (AQUAL)
	40006819	FEED PUMP (AUTO LEC) NEW
	40006815	BOTTOM BODY (FOR 40006819)

40006816	TOP BODY (FOR 40006819)
40006817	VALVE BODY (FOR 40006819)
40006818	DIAPHRAGM (FOR 40006819)
50006809	COVER PLATE WITH GASKET (AQUAL) (N.I.)
50006810	FILTER (AQUAL) (N.I.)
50006811	VALVE PLATE ASS.WITH GASKET (AQUAL)(N.I.)
50006812	PRIMING LEVER WITH SPRING AND SPINDLE (AQUAL)(N.I.)
50006813	DIAPHRAGM ASS. (AQUAL)(N.I.)
50016133	JOINT 0.2 MM
5604580049	JOINT 0.5 MM
560450170	JOINT 0.8 MM
5604580169	JOINT 0.4 MM
5007200048	PIN
D 41931	PIN FOR FEED PUMP (BSII)
50000922	PIN
50000506	STUD
9324018	NUT
1756507	SPRING WASHER
9450030101	FUEL FILTER ASSY.
9451035101	FILTER BOWL
1455523012	COVER
9451037407	ELEMENT
9451030109	SEALING RING
2911161261	BOLT
2916710603	WASHER
9411033412	AIR VENT SCREW
1410107105	WASHER
2916710602	WASHER
9411033412	STUDGE SCREW
1413453025	WASHER
2916710602	WASHER
7500819	BANJO BOLT
50006189	JOINT
500937290	HIGH PRESSURE PIPE
40001008	HIGH PRESSURE PIPE (BSII)
7101901012	BANJO-BOLT-PUMP INLET
1441570056	BANJO BOLT-OVERFLOW
904467015	JOINT-BANJO BOLT
200467003	JOINT-BANJO BOLT
40017130	PIPE FEED PUMP TO FILTER
40017129	PIPE TANK TO FEED PUMP (CARGO)
D31570	PIPE OVERFLOW
91901030	BANJO BOLT-FEED PUMP
94670059	JOINT -BANJO BOLT
D-31152	PIPE FILTER TO PUMP
D-31151	PIPE TANK TO FEED PUMP
D-41186	PIPE TANK TO FEED PUMP
D-41150	PIPE FEED PUMP TO FUEL FILTER
D-31185	PIPE OVERFLOW
D-31153	PIPE OVER FLOW
50000812	BANJO BOLT-FEED PUMP

	904467015	JOINT-BANJO BOLT
	7508831	PLUG
PLATE=8	5406590073	FUEL PUMP ASSY
	D31905	FUEL PUMP(BSII)
	D41531	FUEL PUMP ASSY. MICO
	500458029	SHIM 0.1 MM
	500458023	SHIM 0.3 MM
	500458024	SHIM 5.5 MM
	91200087	"O" RING-FUEL PUMP
	5406578027	ELEMENT
	002B10538	ELEMENT MICO
	5409672029	DELIVERY VALVE
	002B70032	DELIVERY VALVE MICO
	260973027	HEX.SOCKET HEAD SCREW
	422973030	CAP SCREW FOR M8*1025 FOR FUEL PUMP (BSII)
	5762510	PLAIN WASHER
	500721535	TAPPET-FUEL PUMP
	500600036	SPACER
	5306615089	INJECTOR ASSY.
	D41532	INJECTOR ASSY. MICO
	D31904	INJECTOR (BSII)
	5306531433	NOZZEL
	002C40521	NOZZLE MICO
	9324008	NUT
	9676035	STUD
	D-40893	JOINT 2 MM
	D-41236	JOINT 0.5 MM
	D-41237	JOINT 1 MM
	500843036	DOWEL PIN INJECTOR
	500379026	FLANGE INJECTOR
	1756504	WASHER
	D31943	EIP CASING (BSII) (N.I.)
	D42723	JOINT FOR FIP CASING (BSII) (N.I.)
	9756504	SPRING WASHER
PLATE=9	5202569563	AIR COWL
	40001765	AIR COWL 0.7 KW
	5406370420	BACK PLATE
	40001763	BACK PLATE 0.7 KW
	5505066199	AIR BAFFLE (EXHAUST)
	5505066198	AIR BAFFLE (INLET)
	9979037	PHILIPS SCREW
	90979037	PHILIPS SCREW
	9755504	WASHER SPRING
	9177004	BOLT,BACK PLATE
	1177004	BOLT
	1756507	WASHER SPRING
	9177001	BOLT BACK PLATE
	50006404	JOINT
	50007715	EXHAUST MUFFLER
	D-41100	BRACKET,EXHAUST MUFFLER
	1177004	BOLT

	1756507	SPRING WASHER
	809000641	SPRING WASHER
	800000624	NUT
	5405755043	SPRING-AIR BAFFLE
	500450091	JOINT
	40016140	JOINT EXHAUST MUFFLER
PLATE =10	2925840142	STARTER MOTOR
	40005419	STARTER MOTER 0.7 KW
	5406360073	PLATE STARTER
	40001766	PLATE STARTER 0.7 KW DUST PROTECTOR
	40009567	FIYWHEEL WITH RING GEAR 0.7 KW (INELFMA)
	SK-4398	WASHER
	99732037	HEX.SOCKET HEAD SCREW
	40009551	FLYWHEEL,WITH RING GEAR
	9762643	WASHER,PLAIN FLYWHEEL
	D-41099	PULLEY,STARTING
	2836740153	JUNCTION BOX
	40000704	WASHER SPRING
	40009648	RING GEAR STARTER 0.7 KW (INELFMA)
	27602816036	RING GEAR STARTER
	50000434	BOLT FLYWHEEL
	D11989	FLYWHEEL MOUNTED ALTERNATOR INEL
	D42189	ROTAR INEL FMA
	6291157154	FLYWHEEL MOUNTED ALTERNATOR
	2762145014	RUBBER BOOT
	6193361721	CLAMP
	40000477	SCREW STATOR MOUNTING
	26756503	SPRING WASHER
	270973015	HEX SOCKET HEAD SCREW
	250755504	WASHER SPRING
	D22158	REGULATOR GL400
	D42246	SPACER FR PULLEY
	2837362228	VOLTAGE REGULATOR
	50000663	SPACER,STARTING PULLEY
	40000548	STUD
	1324010	NUT
	50000405	SCREW
	184410012(587671	RELAY SOLENOID
	587671	RELAY SOLENOID
	2928335073	SPACER
	5303790040	FLANGE
	D-41240	SAFETY REGULATOR
PLATE=11	127171011	COVER ENGINE SIDE
	128071012	GASKET ENGINE SIDE COVER
	129001014	GASKET PTO FACE
	825420215	"O"RING
	520221019	COVER PLATE
	807000647	LOCK WASHER,CONICAL
	812061620	COUNTER SUNK SCREW
	808000826	PLAIN WASHER
	809000847	SPRING WASHER
	16408	SPRING WASHER M8

	800000820	NUT
	20108	HEX NUT M8
	127102010	HOLLOW DOWEL
	120212012	NEEDLE BUSH
	815084520	STUD M8 *40
	815084525	STUD
	815084025	STUD
	815064025	STUD FOR CLUTCH COVER
	127101016	MAIN HOUSING,GEAR BOX
	811081025	DRAIN PLUG
	120271018	FIBER WASHER
	227910014	GEARBOX DIFFERENTIAL ASSY.
	127911019	OIL DEFLECTOR
	811051824	HEX SCREW
	567741	HEX SCREW M5 *18
	127912013	FIBER WASHER
	802000525	NYLOCK NUT
	12136	NYLOCK NUT M5 FOR APE
	12136	NYLOCK NUT M5
	127910015	GEAR BOX&DIFFERENTIAL ASSY.
PLATE=12	880154209	BALL BEARING
	127201012	CLUSTER GEAR
	127202016	CLUSTERGEAR (NEW MODLE)
	884222808	NEEDLE BUSH
	120204015	WASHER
	120205019	SHIM,HARD BUSH
	523021018	STEM,GEAR OPERATING
	127306018	CROSS
	842004808	CIRCLIP
	523011013	SHOULDERRING
	523012017	SHOULDER RING GEAR 1st O/S
	523013011	SHOULDER RING GEAR 2nd O/S
	523014015	SHOULDER RING GEAR 3rd O/S
	127301018	SPEED GEAR 1st
	127302012	SPEED GEAR 2nd
	127303016	SPEED GEAR 3rd
	127305014	SPEED GEAR 4th
	127307012	SPEED GEAR 4TH
	127304010	MAIN SHAFT
	880204729	BALL BEARING
	880204705	BALL BEARING 6204 ZZ
	841004708	CIRCLIP.(INT.)
	842002006	CIRCLIP (EXT.)
	842001507	CIRCLIP (EXT.)
	122032014	INNER RING
PLATE=13	127640012	GEAR SHIFTER HOUSING ASSY.COMPLETE SR NO 2,4,10,12
	127641016	GEAR SHIFTER HOUSING
	128081017	GASKETFOR GEAR SHIFTER HOUSING
	127660012	SECTOR,CONNECTOR AND PIN ASSY,
	825080209	"O" RING -SECTOR PLATE ASSY.
	126022017	PIN FOR SLIDER BLOCK
	126021013	SLIDER BLOCK

	526023017	SHIFTER LEVER
	126004015	TAPER PIN
	126003011	SPRING-GEAR SHIFTER ASSY.
	126060019	BRACKET SUB ASSY.
	126050014	BRACKET WITH ROLLER ASSY. SR NO.11,13,14,15. (NI)
	126054010	SCREW FOR BRACKET
	126053016	PIN FOR ROLLER
	126052012	ROLLER
	808000620	PLAIN WASHER
	3056	PLAIN WASHER M6
	809000641	SPRING WASHER
	16406	SPRING WASHER M6
	819064530	SCREW SOCKET HEAD
	127650017	SECTOR,CONNECTOR AND LEVER ASSY. SR. NO.4,6,7,8,9
	604560	THREADED TERMINAL ASSEMBLY
	567594	THREADED TERMINAL
	31054	BOLT FOR SCREW TERMINAL
	150418	SMALL DISC
PLATE =14	124140011	FARE METER HOUSING ASSY.SR.NO.2 TO 5&14
	124161015	FARE METER HOUSING
	124112014	BUSH
	125012015	PLUG
	165121014	PIN
	811051525	SCREW (HEX HEAD M5 *15)
	801000528	CHECK NUT
	124105011	PLUG ,FARE METER DRIVE
	224105010	PLUG SHAFT PINION
	124120011	FARE METER PINION WITH SPRING PIN CONSISTING OF 10& 12
	124121015	FARE METER PINION
	124102019	FARE METER GEAR
	822031942	SPRING PIN (PINION FARE METER
	124104017	ADAPTER
	124113018	GREASE NIPPLE
	165031013	GASKET
	127121016	GEARBOX COVER
	120203011	HOLLOW DOWEL
	120302013	BUSH
	822051647	SPRING PIN (R.C. STOPPER)
	880255209	BALL BEARING
	841005207	CIRCLIP
	888472578	OIL SEAL
	127501010	SHAFT PINION
	127401013	REVERSE CONTROL GEAR
	127401014	REVERSE CONTROL GEAR PASSENGER
	127571015	IDLER GEAR
	227571014	IDLER GEAR
	842002501	CIRCLIP
	112898	DIPSTICK ASSY.
	127016015	SEALING WASHER,DIPSTICK
	6450	CIRCLIP
	7066	BALL BEARING
	111353	CIRCLIP

127551015	GEAR FINAL DRIVE
227551014	GEAR FINAL DRIVE(CARGO)
165155	SATELLITE GEAR
132136	DIFFERENTIAL GEAR
132129	PIN SATELLITE GEAR
815084520	STUD
288730	DIFFERENTIAL CAGE
808000826	PLAIN WASHER
809000847	SPRING WASHER
16408	SPRING WASHER M8
808000820	NUT
808000620	PLAIN WASHER
843000809	CIRCLIP
3056	PLAIN WASHER M6
809000641	SPRING WASHER
16406	SPRING WASHER M6
811061623	LOCKING SCREW
31088	HEX HEAD SCREW M6*16
127141016	GASKET
128050018	LEVER AND SECTOR ASSY.CONSISTING OF SR 47,48,49,50&52
228050017	LEVER &&SECTOR ASSY.CONSISTING OF SR.47.48.49.50.52
120321019	SLIDER BLOCK
127151011	LEVER
120322013	LEVER
843000500	CIRCLIP
843000500	CIRCLIP
120309011	SPRING PIN
17702	SPRING PIN R.C.GEAR
127111011	TENSION SPRING (R.C.)
128060013	SECTOR PLATE ASSY. COMPLATE
220363016	COVER PLATE (DIFF. COVER)
168065	SCREW
825080209	O RING SECTOR PLATE ASSY.COMPLATE
825090204	"O" RING
128306015	BRACKET
809000641	SPRING WASHER
16406	SPRING WASHER M6
811061221	SCREW
128307014	BOLT R.C.
128307019	BOLT R.C.
220575	WASHER
132134	CIRCLIP
132244	STOPPER
198618	BELLOW
111356	COVER
31092	SCREW
809000641	SPRING WASHER M6
16406	SPRING WASHER
183511	OIL SEAL
113278	BUSH
587688	PROP.SHAFT LEFT
587687	PROP.SHAFT ASSY.WITH PIN LH

	587686	PROP.SHAFT RIGHT
	112867	SLIDER BLOCK
	113099	PIN FOR PROP. SHAFT
	117401	BUSH
	117402	OIL SEAL
	117404	SPEEDO METER GEAR
	165121014	PIN
	604560	SCREW TERMINAL ASSY.
	12025001	SCREW TERMINAL ASSY.
	127103014	STUD (HOLLOW DOWEL)
	119278	NIPPLE
	111498	ELASTIC HUB
	15578	SCREW
	16410	SPRING WASHER
	800001020(15252)	NUT
PLATE =15	129025010	SPACER WASHER
	127913017	SPACER WASHER CLUTCH
	127760018	CLUTCH SHAFT ASSY.
	121120010	CLUTCH SHAFT ASSY.
	129011019	WASHER FOR CLUTCH ASSY.
	129012013	TAO WASHER
	47177007	BOLT CLUTCH
	811083035	BOLT
	129019011	THRUST PLATE
	129014011	THRUST PLATE
	129015015	SPRING CLIP
	127753015	CLUTCH BOX
	127757011	CUP CLUTCH SPRING
	127755013	SPRING CLUTCH
	127722016	CLUTCH BOX
	121122018	CLUTCH SHAFT
	127790013	CLUTCH SHAFT
	121117013	CUP-CLUTCH SPRING
	121116019	SPRING CLUTCH
	121121014	CLUTCH SHAFT
	121122018	BUSH SINTERED
	127752011	SHIM BRASS
	167758015	SHIM BRASS
	121119011	SHIM BRASS
	127751017	ENGINE GEAR
	127759019	ENGINE GEAR NEW MODLE
	127780018	DRIVEN PLATE ASSY.
	121115015	ENGINE GEAR
	127710013	DRIVEN PLATE ASSY.
	127701012	DRIVING PLATE ASSY.
	127721012	PRESSURE PLATE OUTER
	127754019	CIRCLIP CLUTCH BOX
	825123207	O RING CLUTCH COVER
	127723010	CIRCLIP CLUTCH BOX
	825123207	"O" RING
	120159014	PLUNGER
	127182010	PLUNGER SHAFT ASSY.

	127014017	PLUNGER SHAFT
	822031942	SPRING PIN
	127181016	CLUTCH COVER HOUSING
	127011015	CLUTCH COVER HOUSING
	127184018	CLUTCH COVER (MACHINING)
	127184018	CLUTCH COVER HOUSING-MODI-FIED CABLE
	127185012	SPRING CLUTCH RETURN
	120163015	SPRING CLUTCH RETURN
	120164019	RETAINING PLATE
	842001600	CIRCLIP (EXT)
	801000827	LOCK NUT
	120106017	SCREW ADJUSTER
	127190017	LINK ASSY.
	127020016	LINK ASSY.
	127013013	PIN CLUTCH
	808000620	PLAIN WASHER
	3056	PLAIN WASHER M6
	16406	SPRING WASHER M6
	809000641	SPRING WASHER
	800000624	NUT
	20106	HEX HUT M6
	120133010	SCREW TERMINAL .
	120238016	BOLT FOR SCREW TERMINAL
	120170018	CLIP HOSE
	127012019	BELLOW FOR CLUTCH COVER
	121131019	RING CLUTCH BOX
	825120308	"O" RING (PLUNGER SHAFT)
	162002011	SUPPORT CLIP ENGINE STOP AND ACCELERATOR CABLE
	843000809	CIRCLIP
	127750013	CLUTCH ASSY. COMPLETE (N.I.)
	127914011	OIL DEFLECTOR
PLATE=16	587576	ENGINE FRAME
	56496	EARTHING PLATED CONDUCTOR
	604632	EARTHING CABLE (BRAIDED TYPE) MODIFIED
	569241	SPACER
	568336	SPACER
	604632	EARTHING CABLE (BRAIDED TYPE)
	644839	EARTH CABLE (VE)
	136916	FORK
	587830	THREE WAY CONNECTOR
	587620	REAR BRAKE PIPE LH
	644813	REAR BRAKE PIPE LH
	587622	REAR BRAKE PIPE RH
	800000820(20108)	NUT
	644812	REAR BRAKE PIPE RH
	809000847	SPRING WASHER M8
	16408	SPRING WASHER
	811082029(31117)	SCREW
	31118	HEX HD SCREW M8*20
	604948	HEX HD BOLT M10 *10
	30111	SCREW
	567587	GRILL

265091	RUBBER BUMPER (BELL SPRING)
15335	HEX HD NUT M8
15252	HEX HD NUT M 10
569093	ENGINE ELASTIC SUPPORT
568157	RUBBER BUMPER
800001020	NUT
587634	ENGINE ELASTIC SUPPORT
587640	ENGINE COVER RH
587641	ENGINE COVER LH
587767	ENGINE COVER FRONT
604605	ENGINE COVER ASST.
568738	PLATE FOR SCREW
568475	PLATE FOR SCREW
808000527	WASHER
6078	PLAIN WASHER 12*5.2 *1
30088	HEX HD BOLT M8*10
15911	SELF TAPPING SCREW
30111	HEX HD BOLT M*10
604948	HEX HD BOLT M8*110 WITH POINTING
16408	SPRING WASHER M8
15252	SPRING WASHER M10
30113	SCREW FOR SECURING BUFFER
16410	SPRING WASHER
587621	FLEXIBLE HOSE,BRAKE REAR
644814	FLEXIBLE HOSE; REAR BRAKE
2383	PLAIN WASHER M18 *10.5 *2
16626	PLAIN WASHER
161157015(15235)	NUT
108834	PLATE
31159	SCREW
569375	CAP FOR BUFFER
569244	LOWER PLATE FOR BUFFER
271171	CAP FOR BUFFER
218758	LOWER PLATE FOR BUFFER
587533	SUPPORT ARM ENGINE REAR
15578	BOLT
567524	RUBBER BUMPER REAR SUPPORT BKT.
178610	GROMMET
15478	GROMMET
811081623(31116)	BOLT
3058	WASHER
587523	REAR CROSS MEMBER
811082029(31154)	BOLT
31118	HEX HD SCREW M8*20
800000520	NUT
20108	NUT
16410	SPRING WASHER
241659	BOLT
568260	BOLT
800001020(15252)	NUT
31116	HEX HEAD SCREW M8 *16
587897	UPPER DUCT HOT AIR

	587898	LOWER DUCT HOT AIR
	31054(15733)	SCREW (HOT AIR DUCT)
	811081623(31116)	BOLT (HOT AIR DUCT)
	31058	SCREW(ENGINE COVER)
	16405	SPRING WASHER
	80000521	NUT
	80000521(20105)	NUT (4ST RELAY)
	80800527(6078)	WASHER
	80800527(3055)	WASHER
	286328	PLAIN WASHER
	587895	PLATE SUPPORT
	16603	PLAIN WASHER
	16405	SPRING WASHER
	809000548	SPRING WASHER M5
	20105	NUT
	80000521	NUT M5
	568173	ENGINE COVER MTG.PLATE ASSY.CENTRAL
	568174	ENGINE COVER MTG.PLATE ASSY.FRONT LH
	568175	ENGINE COVER MTG.PLATE ASSY.FRONT RH
	568176	ENGINE COVER MTG.PLATE ASSY. SIDE
	568140	GROMMET
	604516	DC CABLE CONTROL BRACKET (N.I.)
	568192	ENGINE COVER ASSY.
PLATE=17	109012	WLNDSHIELD PACKING
	587963	LAMINATED WINDSCREEN GLASS
	109011	WINDSHIELD GLASS
	587963	LAMINATED WINDSCREEN GLASS (OPTLONAL)
	567683	TANK CAP WITH LOCK
	569223	FUEL TANK (CARGO)
	569225	FULE TANK (PASS)
	643712	FULE TANK (CARGO)
	80000624	HEX NUT M6
	20106	HEX NUT M6
	809000641	SPRING WASHER M6
	16408	SPRING WASHER M6
	887764	FUEL TANK
	587833	FUEL TANK
	80000624	NUT
	16406	SPRING WASHER
	31088	SCREW
	930101011	PASSION MAROON TIUCHUP PAINT
	16406	SPRING WASHER
	568136	BODY CEILING
	107952	REAR GLASS
	107952	GLASS FOR REAR WINDOW
	125707	REAR GLASS PACKING
	604761	PACKING
	604761	REAR GLASS PACKING FIXED
	568083	DRIVE BACKREST
	604580	DRIVE BACK REST (PASSENGER)
	587848	DRIVE BACKREST
	14034	PACKING

568135	PLAIN WASHER
568134	SELF TAPPING SCREW
604579	DRIVER SEAT ASSY. (PASSENGER)
587847	DRIVE SEAT ASSY.
567562	SUPPORT TUBE
587849	DRIVER SEAT SUPPORT PIPE (PASSENGER)
587846	SUPPORT TUBE
185912	DRIVE SEAT .
811082029	SCREW
567563	DRIVER SEAT
31118	HEX HDD SCREW M8*20
3058	PLAIN WASHER
811081623	SCREW
31116	HEX HEAD SCREW M8 *16
20108	NUT
809000847	SPRING WASHER
16408	SPRING WASHER
16408	SPRING WASHER
587763	BREATHER PIPE
567878	TANK UNIT
809000548	SPRING WASHER M5
188400015	FUEL GAUGE TANK UNIT WITH PACKING
16405	SPRING WASHER
31054	BOLT
587601	MAIN FRAME WITH CAB ASSY.
567730	MAIN FRAME ASSY.
568730	(GREEN)MAIN FRAME WITH CABINET ASSY. (CARGO) WITH DOOR
568730	MAROON-MAIN FRAME WITH CABINET ASSY. (CARGO) WITH DOOR
568730	(BLUE) MAIN FRAME WITH CABINET ASSY. WITH DOOR
568730	SAHARA YELLOW) MAIN FRAME WITH CABINET ASSY. WITH DOOR
568730	(BANCO WHITE MAIN FRAME WITH CABINET ASSY. WITH DOOR
568730	GOLDEN YELLOW)MAIN FRAME WITH CABINET ASSY. WITH DOOR
56730	(C.YELLOW MAIN FRAME WITH CABINET ASSY.
587975	MAIN FRAME WITH CABINET ASSY. (PASS) WITH WINDSHIELD
567730	(BLACK)MAIN FRAME WITH CABINET ASSY.(PASS)WITHOUT WINDSHIELD
930101012	CHARMINA BLUE TOUCHUP PAINT
930101015	BRILLIANT GREEN TOUCHUP PAINT
108463	PILLAR LH
587891	WINDSHIELD FRAME
632288	WINDSHIELD ASSY. WITH I.P.
128009	CAPSULE
128010	CAPSULE
568682	FASTNER
125447	FASTENER
567563	SEAT ASSY.
190255	PLUG
125998	PLUG
190517	PLUG FOR CONNECTING S
114279	INSULATING TUBE WIRING CLIP ON CHASSIS
190568	PLUG
568159	GROMMET
105392	GROMMET

	568154	GROMMET FOR HORN WIRE
	811083525	BOLT (FUEL FILTER MTG.)
	809000847	SPRING WASHER M8
	13861	PLAIN WASHER
	16408	SPRING WASHER
	800000820	NUT
	20108	HEX NUT M8
	805000605	NUT
	567921	GROMMET
	568106	GROMMET
	569155	GROMMET
	604606	HEX HDD SCREW M5*20
	809000548	SPRING WASHER M5
	567742	GROMMET
	31057	SCREW
	16405	SPRING WASHER
	800000521	NUT
	20105	HEX NUT M5
	31116	SCREW
	808000826(3058)	WASHER
	809000847	SPRING WASHER M8
	16408	SPRING WASHER
	800000820	HEX NUT M8
	20108	NUT
	30242	SCREW
	827000540	MULTITOOTH LOCK WASHER M5 (N.I.)
	12546	SPRING WASHER
	800000521(20105)	NUT
	118447	WINDSHIELD SIDE PACKING
	569191	WINDSHIELD PACKING BETWEEN DOME (N.I.)
	604591	HOSE CLIP DIESEL O/F (N.I.)
	569333	REAR SLIDING WINDOW ASS.(PLASTIC)COMPLATE FRAME RR V
	930101627	BLACK TOUCH UP PAINT (N.I.)
	930101639	GOLDEN YELLOW TOUCHUP PAINT (N.I.)
	930101641	W.RED TOUCH UP PAINT
	930101653	T.GREEN TOUCH UP PAINT (N.I.)
	930101665	C.BLUE TOUCH UP PAINT (N.I.)
	930101677	S.YELLOW TUCH UP PAINT
	930101689	B.WHITE TOUCH UP PAINT (N.I.)
	930101823	SILVER TOUCH UP PAINT (N.I.)
PLATE=18	587608	DASHBOARD
	604549	DASH BOARD
	632447	DASH BOARD (HAZARD WARNING)
	16670	DASHBOARD SEC. WASHER
	15911	DASHBOARD SEC. SCREW
	8080	DASHBOARD SEC. PLATE
	604548	COVER GLOVE BOX
	587610	COVER,GLOVE BOX
	587611	LOCK GLOVE BOX
	587816	BRACKET
	587815	HINGE
	587814	SPACER

	587870	HOOK, TRUNK LATCH
	587813	LOCK PLATE
	567500	HINGE PIN
	800000428	NUT
	20104	HEX NUT M4
	567893	RIVET
	3054	PLAIN WASHER
	568165	PACKING STRIP
	604684	REINFORCEMENT GLOVE BOX COVER (N.I.)
PLATE =19	587968	APE CARGO D-600"NAME PLATE
	587969	APE AUTO D3S" NAME PLATE
	604789	DIESEL NAME PLATE
	587966	HEX EMBLEM
	226109	DIESEL "NAME PLATE
	587966	PIAGGIO"EMBLEM
	183138	FRONT MUDGUARD
	568702	GASKET FRONT MUD GUARD TOP
	568703	GASKET FRONT MUD GUARD TOP
	195023	PACKING
	567520	BATTERY TRAY
	568290	HOOK BOLT FOR BATTERY
	604691	ANGLE BAR ASSY.
	587909	LOCK SPARE WHEEL AND BATTERY
	568293	ANGLYE BAR ASSY.
	587909	LOCK SPARE WHEEL AND BATTERY
	811062524	SCREW
	30192	HEX HDD SCREW M6*25 CL 8.8
	826000622	METALLIC PLAIN WASHER
	13880	PLAIN WASHER M6
	78307	SPRING WASHER
	800000624	NUT
	20106	HEX NUT M6
	157716	SCREW ANCHOR
	18630	SCREW
	8265	SALF TAPPING SCREW
	567748	SUN VISOR ASSY.
	116103	MUD FLAP FRONT
	116105	CLAMP,FRONT MUDGUARD
	31088	SCREW
	800000624	NUT
	20106	hex nut m6
	16406	SPRING WASHER
	15727	EMBLEM SEC.SCREW
	226164	EMBLEM SEC, CAP
	568291	HALF TIE-ROD
	604890	tie rod assly.
	567515	REGISTER
	568131	PIUG
	31089	SCREW
	568159	GORMMET (+VE CABLE
	190568	PIUG
	13782	PLAIN WASHER(EMBLEM SECURING)

PLATE =20	587614	REAR VIEW MIRROR
	604666	REAR VIEW MIRROR DV-LH
	604665	REAR VIEW MIRROR DV-RH
	643685	OUTER REAR VIEW MIRROR(LH)
	567598	PLAIN WASHER
	16408	SPRING WASHER
	80000820(20108)	NUT
	190393	BEADING FOR THE CONNECTION FRAME CABIN
	190462	SECURING PLATE
	808000424	WASHER
	3054	PLAIN WASHER
	80000428(20104)	NUT
	193953	FRONT RH DOOR PACKING
	193704	FRONT LH DOOR PACKING
	193705	DOOR PACKING UPPER
	632604	FRONT RH DOOR PACKING
	193707	DOOR PACKING REAR
	116839	TOW HOOK
	8432	SELF TAPPING SCREW
	194946	PROTECTION LH
	194947	PROTECTION RH
	190465	TERMINAL
	15911	TERMINAL SEC, SCREW
	76227	GROMMET (DIESEL INLET PIPE)
	182149	REAR MUDGUARD RH/LH
	182150	REAR MUDGUARD RH(N.I.)
	182151	REAR MUDGUARD LH
	567592	WASHER
	604603	RIVET
	567591	RIVET
	142424	REAR MUDFLAP
	587662	RUBBER MAT
	414948	PLUG RUBBER
	142425	RUBBER NAIL
	116498	PACKING
	116498	PACKING
	6044724	GASKET
	587909	LOCK SPARE WHEEL
	569186	RUBBER WASHER
	568741	LOCK WASHER
	14034	O" RING
	190479	PACKING
	8455	SCREW (DIESEL INLET PIPE TO CHASSIS)
	808000527	WASHER
	6078	PLAIN WASHER M5
PLATE =21	183077	UPPER PACKING RH DOOR RABBET
	163660	UPPER PACKING LH DOOR RABBET
	97756	
	5745	RIVET
	6078	PLAIN WASHER
	108800	LOWER BRACKET RH
	152025	UPPER BRACKET LH

	163661	GLASS FOR WINDOW (STEADY)
	163663	PACKING
	140603	SECURITY LOCK CYL. SHIM PLATE
	193724	PLATE
	182663	STOP BLOCK LH DOOR
	182662	STOP BLOCK RH DOOR
	569156	CSK SCREW M6*30
	569157	CSK SCREW M6*40
	8936	SCREW
	8937	SCREW
	30242	SCREW
	827000540	STAR WASHER
	12546	MULTITOOTH LOCK WASHER M5
	182660	LOCK RH
	182661	LOCK LH
	127540	HANDLE GRIP IH (WITH KEY PUSH BUTTON
	569116	DOOR HANDLE LH (W/OKEY)BLACK POWDER COATED
	569115	DOOR HANDLE RH(W/OKEY) BLACK POWDER COATED
	156413	HANDLE GRIP RH (WITH KEY PUSH BOTTON
	163659	SEAL LOWER
	8808	SPRING PIN
	149028	DEFLECTOR CLOSING LEVER RH
	149027	LEVER LH
	156413	DEFLECTIR CLOSING LEVER LH
	149028	LEVER RH
	116971	PACKING
	15727	SCREW
	62961	SPRING
	182654	STOP BLOCK FOR LEVER
	802000525	STOP NUT
	20108	NYIOCK NUT M5
	64263	STOP WASHER (FIBER)
	604558	PINFOR LEVER
	108803	PIN FOR LEVER
	108804	SCREW
	13935	WASHER
	108801	LOWER BRACKET LH
	109263	LOWER BRACKETRH
	31058	SCREW
	6177	WASHER
	108805	SCREW
	163665	GLASS FOR VENT WINDOW
	163666	RH.VENT.WINDOW ASSY.
	163667	LH VENT WINDOW ASSY.
	163671	RH DOOR ASSY.
	163672	LH DOOR ASSY.
	567684	RH,DOOR ASSY.
	567895	LH DOOR ASSY.
	567745	DOOR UPPER HINGE
	8847	SPRING PIN
	13861	PLAIN WASHER
	827000849	LOCK WASHER,

	12540	MULTITOOTH LOCK WASHER
	811083525	SCREW
	8451	SCREW
	89281	PLATE
	568148	STOP BELT FOR DOOR
	182655	KNOB FOR DOOR LEVER
	109579	WHEEL RIM
	2/109579	WHEEL RIM (OPTIONAL)
	587971	TYRE (4.5 *10-8PR)
	151924	INNER TUBE
	567439	JACK
	6018	PLAIN WASHER
	568271	FASTENING FOR DRIVE MIRROR
	567594	FASTENING DRIVE FOR MIRROR (CARGO)
	605389	FASTENING FOR MIRROR
	140728	PLAIN WASHER
	80000820(20108)	NUT
	192021011	DOUBLE END SPANNER 7/8
	567454	DOUBLE END SPANNNER 7/8
	7230052	DOUBLE END SPANNER 10/13
	567455	DOUBLE END SPANNER 10/13
	192024013	DOUBLE END SPANNER 12/14
	567457	DOUBLE END SPANNER 17/19
	9230053	DOUBLE END 17/19
	192007015	SCREW DRIVE
	567458	SCREW DRIVE
	604707	TOOL BAG
	567460	TOOL BAG
	567459	"L TYPE SPANNER
	500405518	STARTING ROPE
	192020017	STARTING ROPE
	163782	DEFLECTOR PANE RABBET REAR GASKIT
	163784	DEFLECTOR PANE RABBET FRONT GASKET
	604689	STOPPER QUARTER WINDOW RH (N.I.)
	108356	SPRING FOR LH LOCK
	115531	SPRING FOR RHLOCK (N.I.)
	8588	SPRING PIN FOR LOCK PAWL (N.I.)
	116334	BOX FOR GUIDE LH LOCK (N.I.)
	109121	LEVER LH (N.I.)
	13842	PLAIN WASHER (N.I.)
	107154	PAWL LH/RH LOCJK (N.I.)
	116333	
	109120	LEVER RH (N.I.)
PLATE=22	568128	TRIANGLE LH REAR SUSPENSION
	644897	TRIANGLE RH COMPLATE
	644898	TRINGLE LH COMPLETE
	587518	TRINGLE LH REAR SUSPENSION COMP.CONSIST
	568129	TRIANGLERH REAR SUSPENSION
	587519	TRIANGLE RH REAR SUSPENSION COPMP.CONSIST
	568289	RUBBER BUMPER
	567586	RUBBER BUMP (HARD)
	231370	NUT

	157103	BUSH -SHOCK ABSORBER
	107827	SPACER
	128633	CONE
	18622	SCREW
	74414	BUFFER
	6066	WASHER
	16410	SPRING WASHER
	21110	NYLOCK NUT
	136451	REAR SHOCK ABSORBER ASSY.
	267068	SHOCK ABSORBER MOUNTING SCREW LOWER
	286328	PLAIN WASHER
	925500	PROTECTION
	827000643	SPRING WASHER
	31084	BOLT
	925501	CAP
	925502	BLEEDING SCREW
	925503	WHEEL CYLINDER
	925519	PISTON
	925518	CYLINDER PACKING
	925520	SPRING
	116086	UPPER SPRING(BRAKE SHOE
	116088	LOWER SPRING (BRAKE SHOE
	115608	SPACER BUFFER
	157012	STRUT OF HAND BRAKE
	272031	REAR BRAKE SHOE LH WITH LEVER
	272030	REAR BRAKE SHOE RH WITH LEVER
	272027	REAR BRAKE SHOE
	108213	COLLAR NUT
	152530	BRAKE DRUM APE-501
	152580	BRAKE DRUM
	107870	CIRCLIP-BRAKE DRUM
	108215	BOLT
	128528	REAR WHEEL AXIE
	644836	REAR WHEEL SHAFT
	128486	NEEDLE BUSH
	136888	REAR WHEEL HUB
	20359	OIL SEAL
	31159	SCREW
	16410	SPRING WASHER
	127850	BRAKE SHOE STOP SPRING
	243303	BALL BEARING
	6650	CIRCLIP
	15594	SCREW
	196302	OIL SEAL
	587617	ELASTIC COUPLING HUB
	137051	RING
	127903	BRAKE BACK PLATE LH
	587769	REAR BRAKE PLATE ASSY. RH (N.I.)
	127902	BRACK BACK PLATE RH
	587770	REAR BRAKE BACK PLATE ASSY.LH
	109892	PROTECTION CAP
	604535	ELASTIC COUPLING

	113450	ELASTIC COUPLING
	3068	WASHER
	231370	NUT
	136430	REAR WHEEL AXLE ASSY. (WITH BOITS)
	644899	REAR WHEEL AXLE ASSY.
	137026	CIRCLIP
	587615	WHEEL CYLINDER ASSY.
	632148	WHEEL CYLINDER ASSY. REAR
	226662	BUSH REAR
	226661	SPACER REAR
	267065	SPACER FRONT
	226596	BUSH FRONT
	267064	WASHER
	237246	PLAIN WASHER
	136426	NUT
	925522	MAJOR KIT WHEEL CYLINDER REAR (N.I.)
	925522	MINORKIT WHEEL CYLINDER REAR (N.I.)
	587519	TRIANGLE RH REAR SUSPENSION COMPLETE CONSISTING 1,55
	587518	TRIANGLE LH REAR SUSPENSION COMPLATE CONSISTING OF1
	587769	REAR BRAKE BACK PLATE ASSY.RH
	587770	REAR BRAKE BACK PLATE ASSY. LH
	231370	NUT
PLATE=23	567710	STEERING COIUMN
	567720	STEERING COLUMN ASSY. WITH SWING ARM
	567731	STEERING COLUMN ASSY. COMPLETE WITH BRAKE DRUM
	568095	NUT
	87067	PLAIN WASHER
	925501	PROTECTION
	127927	PACKING
	31084	BOLT
	925501	CAP
	925502	BLEEDING SCREW
	827000643	SPRING WASHER
	12536	SPRING WASHER
	587624	FRONT BRAKE HOSE
	925507	WHEEL CYLINDER BODY (FRONT)
	925505	CYLINDER PACKING
	925504	PISTON
	925506	SPRING
	116087	RETAINING SPRING UPPER (BRAKE SHOE)
	116088	RETAINING SPRING LOWER (BRAKE SHOE)
	272029	LEADING SHOE (FRONT)
	272027	TRAILLING SHOE (FRONT)
	127850	BRAKE SHOE STOP SPRING
	21216	NUT
	75708	SILENT BLOCK
	569246	FRONT SHOCK ABSORBER
	567816	FRONT SHOCK ABSORBER
	21110	NUT
	16410	SPRING WASHER
	136434	OIL SEAL

6066	WASHER
74414	RUBBER BUSH
127454	PROTECTION CAP
108873	STOP WASHER
567991	UPPER STEERING NUT STEERING
567990	BEARING SEAT UPPER
108871	BEARING SEAT UPPER
108872	UPPER STEERING NUT STEERING
108874	SECURING RING NUT
824053209(14246)	STEEL BALLS)(UPPER)
109064	DUST COVER
567992	UPPER BEARING RACE BOTTOM
109065	UPPER BEARING RACE BOTTOM
6380	STYEEL BALLS (LOWER) 5/16'
824051603	STEEL BALLS (LOWER)
567993	INTERNAL SEAT LOWER BEARING
109067	LINTERNAL SEAT LOWER BEARING
109066	WASHER
153507	UPPER BEARING RACE ASSY.
153508	LOWER BEARING RACE ASSY.
109265	SPLASH GUARD
569255	FRONT SUSPENSION SPRING
30209	BALL BEARING 6302
159176	FRONT SUSPENSION SPRING
107871	CAP
74521	NUT
567473	CIRCLIP
1082213	NUT WITH COLLAR
880154209	BALL BEARING
152580	BRAKE DRUM (FRONT)
567474	FRONT HUB ASSY. WITH STUD
108215	STUD
125289	NEEDLE BEARING
107870	BRAKE DRUM
127928	PLATE
587829	BANJO BOLT
48197	WASHER
587616	WHEEL CYLINDER ASSY.(FRONT)
107732	BUSH
109117	RUBBER BUSH (FRONT SHOCK ABSORBER) /RING
566545	RUBBER BUSH (FRT SHOCK ABSORBER)-MODIFIED
109510	RUBBER BUSH (FRONT SHOCK ABSORBER)
6733	"O" RING
119740	FRONT SUSPENSION SWINING ARM
175316	BRACKET WHEEL CARRIER
137235	STEERING PIN
8771	OIL SEAL
107718	BLOCK BEARING
180433	FRONT AXLE
567472	FRONT WHEEL HUB WITHOUT BEARNING
180431	COIN WASHER
150579	RING

	567734	HANDLE LOCK WITH KEY
	569150	SPRING STEERING LOCK (MODIFIED)
	569148	CIRCLIP STEERING LOCK DIA 16 (INT) N.I.
	925517	MAJOR KIT WHEEL CYLINDER FRONT (KBX 1006)N.I.
	925521	MINOR KIT WHEEL CYLINDER FRONT kbx 1007)N.I.
	604759	RUBBER CAP STEERING COLUMN
	604758	PROTECTION STEERING COLUMN BN.I.
	161180012	HANDLE LOCK WITH KEY
	161009012	SPRING STEERING LOCK
PLATE=24	30103	HANDLE BAR SECURING BOLT
	16626	PLAIN WASHER
	16410	SPRING WASHER
	8000001020	NUT
	21110	HEX NUT M10
	604543	COVER
	127457	COVER
	8985	SCREW
	31089	BOLT
	16406	SPRING WASHER
	6125	WASHER
	109775	GEAR CONTROL LEVER
	60565	SPRING WASHER
	109404	SHOULDER WASHER
	127451	GEAR CONTROL TUBE
	15618	SCREW
	16319	SPRING WASHER
	16620	WASHER
	12138	NUT
	164906	CLUTCH CONTROL LEVER
	141925	GRIP
	197071	ADJUSTER SCREW
	20206	NUT
	20106	HEX NUT M6
	126902	PROTECTOR COLLAR CABLE
	567567	HANDLE BAR
	109635	THROTTLE CONTROL LEVER
	587902	THROTTLE CONTROL TUBE
	109227	BELLOW
	604515	ENGINE STOP CABLE ASSY.
	587625	ENGINE STOP CABLE ASSY.
	802000824	NUT
	2438	LOCK NUT
	604509	INNER STOP CABLE
	604516	D.C. CABLE CONTROL BKT
	632167	D.C. CABLE CONTROL BKT (N.I.)
	604508	INNER CABLE DECOMPRESSION
	587807	INNER STOP CABLE
	587626	DECOMPRESSION CABLE ASSY.
	587809	INNER CABLE DECOMPRESSION
	7608	SPRING WASHER
	30077	BOLT
	587631	ACCELERATOR CABLE ASSY.

	587802	ACCEIERATOR INNER CABLE
	587630	CLUTCH CABLE ASSY.
	604779	CLUTCH CABLE ASSY. MODIFIED
	587806	CLUTCH INNER CABLE
	587628	CABLE ASSY. GEAR (DARK GREY)
	587919	CABLE ASSY.GEAR (LIGHT GREY)
	587803	GEAR CABLE ASSY.
	587627	SPEEDO CABLE ASSY.
	587812	CABLE SPEEDO INNER
	125181	SPACER
	90511	TERMINAL
	119928	LEVER
	119927	KNOB (RED)
	117271	KNOB (BLACK)
	119181	NYION SPACER
	119278	NIPPLE
	118806	DUST PROTECTION
	587904	WASHER
	604562	CABLE TERMINAL (D.C.&& STOP)ASSY.
	150417	TEADED TEMINAL (DC & STOP)
	150418	SMMALL DISC
	567705	SCREW
	604562	CABLE TERMINAL (ACCELERATOR)ASSY.
	150417	THREADED TERMINAL (ACCELERATOR)
	14745	SCREW
	90527	TERMINAL GEAR CABLE CONTROL
	158495	ADJUSTMENT SCREW WITH NUT
PLATE =25	587618	TANDEM MASTER CYLINDER WITH RESERVOIR
	604615	TANDEM MASTER CYLINDER MODIFIED BRAKE PEDEL
	587773	BRAKE RESERVOIR
	587702	PUSH ROD
	587645	PIN
	587679	FOOT BRAKE PEDAL ASSY.
	604760	FOOT BRAKE PEDAL ASSY, WITH PAD MODIFIED
	567461	RUBBER PROTECTION-BRAKE PEDLE
	80000820(20108)	NUT
	31122	SCREW
	925508	MAJOR KIT-TMC
	925509	MINOR KIT-TMC
	16408	SPRING WASHER
	604502	CUP RETAINING SPRING
	116232	CAP
	568162	BRAKE BUNDY TUBE (TMC TO 3 WHY CONNECTOR)
	12761	SPLIT PIN
	587620	BRAKE BUNDY TUBE REAR LH
	644813	BRAKE BUNTY TUBE REAR LH
	587622	BRAKE BUNDY TUBE REAR RH
	644812	BRAKE BUNTY TUBE REAR RH
	177949	GROMMET FOR BUNDY TUBE
	5969	CIRCLIP
	808001026(6173)	WASHER
	108785	SPRING

	108788	WASHER
	567690	REVERSE GEAR SPRING
	125411	REVERSE GEAR CONTROL LEVER
	117271	KNOB
	587633	REVERSE GEAR CONTROL CABLE ASSY.
	587822	REVERSE GEAR CONTROL CABLE INNER
	1482210016	HAND BRAKE LEVER ASSY, CONSISTS OF SR NO 14.28.29.42
	148203013	PULLEY
	567898	PULLEY FOR HAND BRAKE
	148204017	PIN
	567899	CLEVIS PIN
	148202019	RATCHET HAND BRAKE
	567897	RATCHET-HAND BRAKE
	808001026	PLAIN WASHER
	6173	PLAIN WASHER M10
	6411	CIRCLIP
	800000820	NUT
	20108	HEX NUT M8
	567719	HAND BRAKE CABLE ASSY,
	568161	BRAKE BUNDY TUBE FRONT
	16408	SPRING WASHER
	6414	CIRCLIP
	6408	CIRCLIP FOR SHAFT
	567920	SPLIT PIN FOR SHAFT-ALTERNATE FOR CIRCLIP
	3058	PLAIN WASHER
	587928	SPRING BRAKE PEDLE
	229524	WASHER
	138237	CAP RUBBER
	148220011(567746)	HAND BRAKE LEVER ASSY,
	119278	NIPPLE
PLATE =26	587827	WIPER BLADE WITH ARM
	632292	WIPER BLADE
	569198	ASSY. WIPER MOTOR RACK TYPE
	632284	WIPER MOTOR ASSY.
	569166	MOUNTING BRACKET
	925572	BRUSH CARD ASSY.
	569177	STRAP ASSY.
	632415	STRAP ASSY.
	569178	RUBBER PAD
	569197	WHEEL BOX ASSY.
	569199	BUNDY TUBE
	632285	BUNTY TUBE (WHEELSIDE)
	604506	BUNTY TUBE OUTER
	569165	DOME CAP NUT-WIPER BLADE
	925567	GEAR PLATE ASSY.
	925570	ARMATURE ASSY.
	925571	CABLE RACK
	587653	HORN ASSY.
	604667	HORN SEALED TYPE DIA 75
	604667	HORN ASSY.
	71503	SCREW SECURING SWITCH
	186454	MAIN SWITCH ASSY;

	604557	BLADE FUSE (10 A)
	252945	FUSE 7 5A
	587650	BATTERY 12V 50 AH
	568699	BATTERY 12V 50 AH (DRY CHARGE)
	925510	TAILLAMP LENSE LH
	925582	TAIL LAMP LENSE LH MODIFIED NEOLITE
	925511	TAILLAMP LENSE RH
	925583	TAIL LAMP LENSE RH MODIFIED NEOLITE
	925512	PACKING
	181746	INDICATOR BULB 12V 10W
	925581	INDICATOR BULB 12V 21 WAMBER COLOUR
	567700	STOP AND PARKING BULB 12V 5/10W
	604547	TAIL LAMP ASSY. LH/TELL TELES CLUSTER
	604672	TAIL LAMP ASSY LH/ TELL TELES CLUSTER MODIFIED
	643704	TAIL LAMP ASSY (LH)
	604671	TAIL LAMP ASSY RH MODIFIED
	643705	TAIL ASSY. (RH)
	587647	CLUSTER ASSY.(TELL LATE)
	604793	CLUSTER ASSY.ENGINE TECH
Column2	Column3	Column4
	182103017	INDICATOR BULB 12V 10W
	182202019	STOP AND PARKING BULB 12V 5/10W
	587656	TAILLAMP ASSY. LH
	587657	TAILLAMP ASSY. RH
	183310019	CLUSTER ASSY. (TELL TALE)
	16408	HORN BKT.SECURING WASHER
	150041	LAMP FOR THE INNER CABIN
	150920	LAMP FOR THE INNER CABIN
	282105014	BULB 12V5W
	71633	BULB 12V5W
	15727	SALF TAPPING SCREW
	587652	FLASHER
	632479	FLASHER /TERN SIGNAL FLASHER 21W
	12546	PLAIN WASHER
	31054	SALF TAPPING SCREW
	80000820	HORN BKT. SECURING NUT
	20108	HEX NUT M8
	150915	REGISTRATION PLATE LAMP ASSY.
	12536	LOCK WASHER FOR NUMBER PLATE/SPRING WASHER
	282105014(71633)	BULB 12V 5W
	568727	BULB 12V 2W/BULB CLUSTER
	925513	BULB 12V 2W
	567581	FUSE BOX WITH FUSE
	31058	FUSE BOX SCREW
	567498	BRAKE SWITCH/REVERSE LIGHT SWITCH
	15996	BOLT
	808000424	WASHER
	3054	WASHER/PLAIN WASHER
	587826	HORN PROTECTION
	567582	FUSE HOLDER
	567706	FUSE 30A

	182101019(181747)	REVERSE LAMP BULB 12V 5W
	802000525(20105)	NUT
	12136	NUT/NYLOCK NUT M5
	808000527(3055)	PLAIN WASHER
	6078	PLAIN WASHER 12*5.2*1
	16405	SPRING WASHER
	567733	BKT.FUSE HOLDER
	808000527	PLAIN WASHER
	6078	PLAIN WASHER 12*5.2*1
	6965	SPRING WASHER
	800000521	NUT
	20105	NUT HEX NUT M5
	77055	GROMMET
	31056	SCREW
	6965	SPRING WASHER
	800000521	NUT
	20105	NUT/HEX NUT M5
	567747	STOP BRAKE SWITCH PROTECTION
	568146	SPACER
	568103	ONE WAY FUSE HOLDER
	15911	SCREW
	6044554	BULB HOLDER1POLE CLUSTER ASSY.
	604555	BULB HOLDERII POLE CLUSTER ASSY,
	568714	BATTERY COVER PASSENGER
	925573	MAJOR KIT RR WHEEL CYLINDER
	925574	MINOR KIT RR WHEEL CYLINDER
	925584	BULB(N.I.)
	925585	SCREW LENSE MOUNTING N.I.
	925586	LENSE MOUNTING SCREW
	925589	LENSE MOUNTING SCREW
	925605	TAIL LAMP GLASS RH N.I.
	925604	TAIL LAMP GLASS LH N.I.
	925607	TAIL LAMP HOSING N.I.
	925606	TAIL LAMP GLASS SCREW
	569166	WIPER MOTOR MOUNTING BRACKET
	632284	WIPER MOTOR ASSY. (RACK TYPE)
	604506	BUNDY TUBE OUTER
	632285	BUNDY TUBE (MOTOR TO WHEEL BOX)
	632292	WIPER ARM AND BLADE ASSY.
	569197	WHEEL BOX ASSY.
	569165	DOME NUT
	569177	STRAP ASSY FOR WIPER MOTOR
	569178	RUBBER PAD FOR WIPER MOTOR
	16406	SPRING WASHER M6
	20106	HEX NUT M6 N.I.
	3056	PLAIN WASHER N.I.
PLATE=27	182152	HEADLAMP HOLDER PROTECTION RH
	182153	HEADLAMP HOLDER PROTECTION LH
	616900	HEAD LAMP HOLDER PROTECTION RH MODIFIED
	616901	HEAD LAMP HOLDER PROTECTION LH MODIFIED
	8080	PLATE
	8455	SCREW

	124449	HEADLAMP
	15641	HEADLAMP ADJUSTING SCREW
	114121	BULB HOLDER
	114122	CAP
	587659	HEADLAMP LH ASSY.
	587660	HEADLAMP RH ASSY.
	632478	HEAD LAMP LH ASSY./LAMP FR LHASSY.
	632477	HEAD LAMP RH ASSY. LAMP TR RH ASSY. MODIFIED
	8432	SCREW FOR FIXING PARKING LAMP ASSY.
	219528	BULB 12V 35/35W
	182103017(181746)	INDICATOR LIGHT BULB 10W
	925581	INDICATOR LIGHT BULB 12V 21WAMBER COLOUR
	119735	PROTECTION SECURING SPRING
	127179	SPRING FOR HEADLAMP
	185843	HEADLAMP SUPPORT
	15900	HEADLAMP SECURING SCREW
	567593	BULB 12V 5W
	127177	FRONT PARKING LAMP BODY,RH
	127176	FRONT PARKING LAMP BODY LH
	180004	FRONT PARKING LAMP LENSE RH
	180021	FRONT PARKING LAMP LENSE LH
	925579	FRONT PARKING LAMP LENSE RHMODIFIED
	925580	FRONT SIDE INDICATOR LAMP LENSE LH MODIFIED NEOLITE
	925578	FRONT SIDE INDICATOR LENSE LH MODIFIED LUMAX
	925577	FRONT SIDE INDICATOR LENSE RH
	587670	SWITCH (3 POSITION)
	180022	FRONT PARKING LAMP ASSY. RH
	180023	FRONT PARKING LAMP ASSY. LH
	616900	FRONT SIDE INDICATOR LAMP ASSY. RH MODIFIED
	616901	FRONT SIDE INDICATOR LAMP ASSY.LH MODIFIED
	183030011(587649)	IGNITION SWITCH ASSY.
	632696	IGNITION SWITCH ASSY.
	587974	WIPER MOTOR SWITCH
	119975	GROMMET
	587672	AMPERE METER
	632407	AMPERE METER WITH SPACER RING ASSY.
	632407	AMPEAR METER
	587673	FULE GAUGE
	632408	FUEL GAUGE WITH SPACER RING ASSY.
	632408	FUEL GAUGE
	587939	SPACER
	587674	SPEEDOMETER
	587671	RELAY SOLENOID
	587995	BULB HOLDER AMMETER/FUEL GAUGE
	568728	BULB AMMETER /FUEL GAUGE
	604555	BULB SPEEDOMETERHOLDER
	568727	BULB SPEEDOMETER
	632262	HAZARD WARNING SWITCH
PLATE=28	587666	OPEN BOX BODY COMPLETE
	568704	GOLDEN YELLOW OPEN BOX BODY COMPLATE
	587535	OPEN BOX BODY COMPLETE
	568704	GREEN OPEN BOX BODY COMPLETE

568704	(MAROON)OPEN BOX BODY COMPLETE
568704	BLUE-OPEN BOX BODY COMPLETE
568704	SAHARA YELLOW) OPEN BOX BODY COMPLETE
568704	(BANCO WHITE) OPEN BOX BODY COMPLETE
8265	SELF TAPPING SCREW
811082524	BOLT
31119	BOLT/HEX HD SCREW M8 *25
567578	LOCK SETY WITH KEYS
604530	LOCK SET WITH KEYS
643500	LOCK SET WITH KEYS N.I.
587667	OPEN BOX BODY
193756	SIDE PANELS FOR OPEN BOX BODY
193758	SIDE PANEL FOR OPEN BOX BODY LH/DOOR CENTRAL
567480	TAIL GATE
567478	TAIL GATE
568273	ENGINE INSPECTION COVER
109361	STOP BUFFER FRONT
225814	DAMPER COVER
8451	SELF TAPPING SCREW
128804	LEVER LH SECURING SIDE PANELS
128805	LEVER RH SECURING SIDE PANLES
109212	SPACER
109213	SPRING BUSH
30074	SCREW
16408	SPRING WASHER
800000820	NUT
20108	HEX NUT M8
3057	WASHER
12778	SPLIT PIN
127046	STOP BUFFER
587964	REFLECTOR
16405	SPRING WASHER
802000525	NUT
20105	NUT/NYLOCK NUT M5
567945	REGISTRATION NO PLATE
826000529(16603)	PLAIN WASHER
15727	SCREW
31087	SCREW
16406	SPRING WASHER
800000820(20108)	NUT
3057	WASHER
12778	SPLIT PIN
127046	STOP BUFFER
587964	REFLECTOR
16405	SPRING WASHER
802000525(20105)	NUT
567945	REGISTRATION NO PLALE
826000529(16603)	PLAIN WASHER
15727	SCREW
31087	SCREW
16406	SPRING WASHER
800000624(20106)	NUT

	12138	OPEN BOX BODY SECURING NUT
	3058	WASHER SECURING LEVERS TO SIDE PANELS
	5967	CIRCLIP
	567572	ENGINE INSPECTION LAMP WITH BULB
	282105014(71633)	BULB
	567732	STOP BUFFER FOR RR GATE
	80000624(20106)	NUT
	16406	SPRING WASHER
	568746	(GOLDEN YELLOW)PLATFORM FOR DAC W/O ENGINE COVER
	568746	PLATFORM FOR DAC W/O ENGINE COVER (GREEN)
	568746	PLATFORM FOR DAC W/O ENGINE COVER(MAROON)
	568746	PLATFORM FOR DAC W/O ENGINE COVER(BLUE)
	568746	SAHARA YELLOW) PLATFORM DAC W/O ENGINE COVER
	568746	(BANCO WHITE)PLATEFROM FOR DAC W/O ENGINE COVER
PLATE =29	567994	CLOSED BOX BODY ASSY.
	604844	GOLDEN YELLOW CLOSED BOX BODY ASSY.
	604844	GREEN CLOSED BOX BODY ASSY.
	604844	(MAROON)
	604844	BLUE CLOSED BOX BODY ASSY.
	604844	BANCO WHITE CLOSED BOX BODY ASSY.
	225814	COVER FOR DAMPER HOLES
	8451	SELF TAPPING SCREW
	109361	STOP BUFFER
	282105014(71633)	BULB 12V 5W
	567575	LAMP ASSY.WITH BULB
	567576	LAMP ASSY.WITHOUT BULB
	8103	BUSH BUTTON SWITCH
	15727	SELF TAPPING SCREW
	15846	SWITCH SECURING SCREW
	17701	SPRING PIN
	604531	LOCK SET WITH KEYS (DELIVERY. VAN
	567880	LOCK SET WITH KEYS (DELIVERY WITHOUT DOOR)
	198101	GAS SPRING
	148031	CEILING
	568151	PACKING
	147933	FRAME SIDE LOWER PANEL
	148028	UPPER PANEL FRAME SIDE ASSY.
	1487028	UPPER PANEL FRAME SIDE
	148026	PANEL FRAME SIDE
	257094	HANDLE ASSY. WITH LOCK AND KEY
	257091	HANDLE ASSY. WITH LOCK AND KEY
	802000521(12136)	NUT
	567569	UPPER REAR HATCH
	604770	UPPER REAR HATCH /REAR UPPER HATCH WITH P
	604563	SCREW TERMINAL ASSY.
	115817	SCREW TERMINAL
	31084	SCREW
	568163	STOPPER LEVER
	8451	SCREW
	140090	HOOK CONTROL PULLER
	141663	LOCK PAWL
	141666	PIN DOWEL

	8847	PIN
	141664	SPRING
	129163	OUTER PROFILE
	567476	REAR LOWER HATCH
	567732	STOP BUFFER
	117135	ENGINE CONTROL FLAP
	568273	ENGINE CONTROL FLAP/DOOR ASSY.
	3058	PLAIN WASHER
	16408	SPRING WASHER
	80000820(20108))	NUT
	142238	CENTRAL STRUT
	129159	IN INTERMEDIATE RIB
	141370	EXT. REAR ANGLE LH
	80000521(20105)	NUT
	567753	REAR LH PILLER
	142238	CENTRAL STRUT
	567698	DOOR SPACE PROFILE
	31087	SCREW
	809000847	SPRING WASHER/M8
	16406	SPRING WASHER
	80000624(20106)	NUT
	811082524(31119)	CLOSED BOX BODY SECURING SCREW
	12138	CLOSED BOX BODY SECURING NUT
	129155	REAR ANGLE RH
	587964	REFLECTOR
	8265	SELF TAPPING SCREW
	826000529(16603)	PLAIN WASHER
	567703	WIRE
	567582	FUSE HOLDER WITH FUSE (1*30)AMP
	604557	FUSE 10 AMP
	12778	RING SPLIT PIN
	290402	FUSE HOLDER WITH FUSE 7.5 A
	252495	FUSE 7.5.A
	5967	RING
	16405	SPRING WASHER
	217166	LEVER CONTROL PIN
	217167	PLATE FOR PULLER LEVER ASSY.
	142244	PACKING
	567945	REGISTRATION NO. PLATE
	643661	REGISTRATION PLATE ASSY.
	80000624(20106)	NUT
	16406	SPRING WASHER
	567579	LOCK SET WITH KEYS N.I.
	643501	LOCK SET WITH KEYS (DELIVERY VAN)
	567701	WIRE;BATTERY TO FUSE
	567702	WIRE
	568164	DELIVERY VAN WIRING HARNESS GROUP CONSISTINGNO 53,64
PLATE NO=30	587786	HOOD FRAME ASSY.(CAGE CANVAS)
	604700	HOOD FRAME PIPE
	604701	HOOD FRAME PIPE
	604702	HOOD FRAME PIPE
	604703	HOOD FRAME PIPE

604704	HOOD FRAME PIPE
604705	HOOD FRAME PIPE
604706	HOOD FRAME PIPE
587940	SOFT TOP ASSY.
587907	BELT RETAINER
604578	PASSENGER SEAT ASSY.
587796	SEAT PASSENGER
587798	REAR DOOR
568705	(C.YEIIOW REAR BODY ASSY./PASSENGER BODY ASSY. COMPL
587844	REAR BODY ASSY.
(38)9000	SELF TAPING SCREW
587955	REAR CARPET
587961	PROFILE SHORT FOR CARPET
587962	PROFILE LONG FOR CARPET
15996	OPEN BOX BODY SECURING BOLT
8080000424(3054)	OPEN BOX BODY SECURING WASHER
587964	REFLECTOR
16405	SPRING WASHER
800000521(20105)	NUT
568273	ENGINE INSPECTION FLAP
567732	RUBBER BUFFER, RR GATE
8451	SELF TAPPING SCREW
225814	COVER
567945	LICENSE NO HOLDER
643661	REGISTRATION PLATE ASSY.
811081623(31119)	SCREW
3058	PLAIN WASHER
16408	SPRING WASHER
8432	SCREW
587948	CLAMP CANVAS
567533	PROFILE SIDE
643752	LATERAL PROFILE FOR COVER
568275	RUBBER BUMPER
811082029(31117)	SCREW
3058	PLAIN WASHER
16408	SPRING WASHER
31088	SCREW
31090	SCREW
808000622(3056)	PLAIN WASHER
16406	SPRING WASHER
567968	LH PANEL
567966	RH PANEL N.I.
15911	PAN SELF TAPPING SCREW
18536	SCREW
14628	SCREW
80000624(20106)	NUT
16404	SPRING WASHER
604583	LOCK SET WITH KEYS
643502	LOCK SET WITH KEYS (PASSENGER)
568686	CLOSURE FRONT RH ASSY.
568687	CLOSURE FRONT LH ASSY. N.I.
567580	LOCK SET WITH KEYS N.I.

	567944	CLOSURE FRONT RH ASSY.
	567943	CLOSURE FRONT LH ASSY. N.I.
	15900	SELF TAPPING SCREW
	567872	REAR CARPET RH
	567873	REAR CARPET LH
	567874	PROFILE INTERMEDIATE CARPET
	15911	SELF THREADING SCREW
	16670	WASHER
	567534	PROTECTION FABRIC RH
	567535	PROTECTION FABRIC LH
	16670	PLAIN WASHER
	604604	REAR CARPET- PASSENGER ROOM
	604581	HANDREST TUBE ASSY.
	587921	REAR CARPET-PASSENGER ROOM
	567457	HANDREST TUBE ASSY.
	568325	FAREMETER SUPPORT PLATE
	569756	REAR VISUAL BARRIER
	643670	REAR VISHAL BARRIER
	567955	REAR VISUAL BARRIER
	568107	FAREMETER CABLE N, I.
	16408	SPRING WASHER
	800000520(20008)	NUT
	30074	HEX HEAD SCREW
	16408	SPRING WASHER
	31116	SCREW
	16408	SPRING WASHER
	709046	NUT
	604538	HANDLE COPVER GRIP
	604539	HANDLE
	632437	CARPET PICKUP PLATFORM
PLATE =31	587932	WIRING HARNESS MAIN
	644903	WIRING HARNESS MAIN
	604611	WIRING HARNESS MAIN
	604537	WIRING HARNESS MAIN
	604794	WIRING HARNESS MAIN
	604814	WIRING HARNESS MAIN FOR NEW AIRCLEANER
	587913	WIRING HARNESS DASH BOARD
	644902	WIRING HARNESS DASHBOARD
	604536	WIRING HARNESS DASHBOARD
	604610	BATTERY CABLE NEGATIVE
	644838	BATTERY CABLE NEGATIVE
	567566	BATTERY CABLE NEGATIVE
	31088	HEX. SCREW
	808000622(3056)	WASHER
	16406	SPRING WASHER
	604609	BATTERY CABLE GROUP
	644837	BATTERY CABLE POSITIVE
	567437	BATTERY.CABLE POSITIVE
	567484	STARTER CABLE GROUP
	811081623(31116)	BOLT
	3058	WASHER

PLATE NO=32	616541	BACK PLATE ASSY.FRONT
	602126	LEADING SHOE WITH PIN LH
	602131	TRAILING SHOE COMPLETE
	179056	STRUT SUB ASSY.LH
	178804	FROK FOR LH WHEEL
	178805	STRUT FOR LH WHEEL
	178806	SPROCKET FOR LH WHEEL
	602497	SHOE HOLD DOWN SPRING
	116088	SPRING SUPPORTING JAWS
	245038	SHOE RETURN SPRING
	178808	LEVER RETURN SPRING
	178807	ADJUSTER LEVER LH
	178823	BRIDGE LH
	63440	HEX BOLT M6*12
	12536	SPRING WASHER
	587616	WHEEL CYLINDER ASSY.FRONT (22.225 MM)
	XXX	GROMMET
PLATE=33	587615	WHEEL CYLINDER ASSY RR (25.4 MM)
	632148	WHEEL CYLINDER ASSY.RR 25.4 MM
	602120	BACK PLATE ASSY LH
	602123	BACK PLATE ASSY.RH
	602126	LEADING SHOE WITH PIH LH
	602128	LEADING SHOE WITH PIN RH
	602050	TRAILLING SHOE WITH HBL LH
	602118	TRAILLING SHOE WITH HBL RH
	179056	STRUT SUB ASSY.LH
	179057	STRUT SUB ASSY RH
	178804	FORK FOR LH WHEEL
	178818	FORK FOR RH WHEEL
	178805	STRUT FOR LH WHEEL
	178820	STRUT FOR RHWHEEL
	178806	SPROCKET FOR LH WHEEL
	178819	SPROCKET FOR RH WHEEL
	602497	SHOE HOLD DOWN SPRING
	116088	SPRING SUPPORTING JAWS
	245038	SHOE RETURN SPRING
	63440	HEX BOLT M6*12
	12536	SPRING WASHER
	178808	LEVER RETURN SPRING
	178807	ADJUSTER LEVER LH
	178821	ADJUSTER LEVER RH
	178823	BRIDGE LH
	178824	BRIDGE RH

PLUG

u

G OF SR.NO.6.7.8

OF SR.NO 6,7,8,

2,13

OR
)OR

)R

OR

NDSHIELD

MINDOW

5,56,57,58,59.

.55.56.57.58.59.

.ATE